

Carl Zeiss Cameras

## Zeiss Ikon SuperWide

### Enjoy infinite range

To some, the pursuit of photographic purity is both a creative challenge and a personal passion. Free from complicated cameras and unnecessary features, they pursue their vision in the purest form, relying on their experience and skill to create the ideal image. The **Zeiss Ikon SuperWide** was created for these rare individuals. It refines the idea of an uncomplicated camera and the simplicity of photography to the extreme. It foregoes an elaborate rangefinder and focuses entirely on photography with super wide-angle lenses. An accessory shoe directly above the optical axis accommodates an optional viewfinder that is matched to the lens. The second accessory shoe is equipped with a direct X-contact and intended for attachable flashes, levels and other accessories. With the exception of the rangefinder, the camera possesses the same features as the Zeiss Ikon rangefinder camera. The exposure setting is shown on a special LED display on the back of the camera. The **Zeiss Ikon SW** is available with a black or silver finish.



**Zeiss Ikon SuperWide**



We make it visible.

## Technical Specifications

### Zeiss Ikon SuperWide

<b>Camera type</b>	Super wide-angle camera
<b>Film format</b>	35 mm film
<b>Lens mount</b>	M-bayonet
<b>Viewfinder</b>	Two accessory shoes for add-on viewfinders
<b>Exposure meter</b>	Center-weighted TTL-system, aperture priority auto exposure control with AE lock or manual exposure control
<b>TTL metering range</b>	With ISO 100 and f/2: EV0-19 (f/2: 4 s, f/16: 1/2000 s)
<b>Film speed</b>	Adjustable: ISO 25 – 3200 (1/3 stop intervals)
<b>LED-Display</b>	Shutter speed range Shutter speed warning Battery status
<b>Shutter</b>	Metal shutter blades, opens vertically, electronically controlled
<b>Shutter speed</b>	1/2000 s to 8 s, Bulb
<b>Flash synchronization</b>	1/125 s or longer, X-contact, X-sync
<b>Film transport</b>	Manual advance with rapid wind lever, Rewind via crank
<b>Tripod-thread</b>	¼" in base plate
<b>Batteries</b>	2 x 1.5 V, type LR44, SR44, 1x Lithium CR 1/3
<b>Overall dimensions</b>	138 x 72.5 x 32 mm (5.4 x 2.8 x 1.3")
<b>Weight</b>	410 g (14.5 oz.)

## Optional

### Accessories



#### Add-on viewfinder

The high-quality attachable viewfinder enables convenient image composition with wide-angle lenses. Available for focal lengths of 15, 18, 21/25 and 25/28 mm.



#### Camera leather case

The 38 g (1.34 oz.) attachable side grip makes it easier to grip and hold the camera. Additionally, it provides a ¼" tripod thread directly under the optical axis.



#### Camera leather case

The high-quality black case made of real leather with a black velvet lining protects the camera against jolts, shaking and rain during transport and during breaks. Is screwed on to the camera. Simply open the front to start taking pictures.

## Technical

### Highlights

- Analog 35 mm camera with an M bayonet
- Specializes in super wide-angle photography with an attachable viewfinder
- Provides a second accessory shoe with a direct X-contact for attachable viewfinders, flashes or levels
- Center-weighted TTL exposure metering with practical exposure correction and separate exposure storage lever; exposure times can be read on a special display
- Metal shutter blades open vertically (1/2000 – 8s, B setting, flash synchronized to 1/125s or longer)

Carl Zeiss AG

Camera Lens Division

D-73446 Oberkochen · Germany

[www.zeiss.com/photo](http://www.zeiss.com/photo)